Airtight window and door junctions

Keep the air seal continuous while retaining designed ventilation.

Build Supply | SulfRock | Intelligent Panel Systems | HomePod

1 Agree the junction

Identify the air-control layer, outer weather seal, insulation and drainage routes on an approved detail.

2 Prepare the surfaces

Use clean, sound substrates. Confirm primer, temperature and moisture limits with the tape or sealant supplier.

3 Allow movement

Select compatible flexible products and the specified joint geometry. A surface bead alone may not seal the hidden junction.

4 Keep water routes open

Do not obstruct drainage holes, cavity trays or weeps. Inner airtightness and outer weather protection serve different functions.

5 Check ventilation

Maintain the ventilation strategy, including required background vents, extract and purge provision.

6 Verify before covering

Inspect corners and penetrations, photograph the work and use project air testing to find leakage.

Seal uncontrolled leakage; provide fresh air through the designed ventilation system.

REFERENCE GUIDANCE

GOV.UK: Approved Document F
GOV.UK: resistance to moisture research

Use current product instructions and the approved project design. For regulations, confirm the UK nation, applicable edition and transitional arrangements.

Help us keep our information accurate.

If you notice an error, outdated information or something that needs clarification in this document, please let us know.
Report an Issue: Visit our website and select Report a Website or Document Issue.
intelligentpanelsystems.co.uk