# Waterproofing: checks before handover

Use a complete compatible system and record concealed work.

Build Supply | SulfRock | Intelligent Panel Systems | HomePod

### 1 Substrate and falls

Check soundness, dryness limits, drainage falls and outlet levels against the chosen system design.

### 2 Product and preparation

Confirm compatible primer, membrane, reinforcement and protection. Follow mixing and application instructions.

### 3 Joints and penetrations

Use approved details for corners, movement joints, upstands, outlets and pipe entries.

### 4 Weather and thickness

Record application conditions, coverage and specified thickness. Allow the required cure before subsequent work.

### 5 Protect the membrane

Use the specified protection for traffic and later trades. Screed is appropriate only where the system requires it.

### 6 Choose the test

Agree the inspection and integrity-test method. Flood testing requires suitable construction, load checks and manufacturer approval.

**Record the detail, inspect it and test by a method suitable for that system.**

## REFERENCE GUIDANCE

LRWA: liquid waterproofing design guidance
LRWA: technical guidance and testing

Use current product instructions and the approved project design. For regulations, confirm the UK nation, applicable edition and transitional arrangements.



**Help us keep our information accurate.**

If you notice an error, outdated information or something that needs clarification in this document, please let us know.
Report an Issue: Visit our website and select Report a Website or Document Issue.
intelligentpanelsystems.co.uk